

1. Review the diagrams thoroughly.
2. All electrical connections must be in accordance with local codes, ordinances and the national electric code.
3. Disconnect the power at the fuse or circuit breaker before servicing or installing.
4. Do not use outdoors.
5. Do not mount hazardous locations or new gas or electric heaters.
6. Do not let the power cords touch a hot surface.
7. Equipment should be mounted in locations and at heights where it will not be subject to tampering by unauthorized personnel.
8. The use of accessory equipment is not recommended by the manufacturer as it may cause an unsafe condition.
9. Do not use this equipment for anything but its intended use.
10. All servicing should be performed by a certified electrician.
11. All the battery to charge for 24 hours before the first use.

WIRING DIAGRAM (see FIG# 1)

AC Wiring

Connect the white wire to neutral.

If using 120V, connect the black wire to the hot lead.

If using 347V, connect the red wire to the hot lead.

Cap the unused lead.

UDC Wiring



6-24V DC input, yellow wire is positive (+), purple is negative (-)

CANOPY ASSEMBLY (see FIG# 2)


Insert canopy into housing at a 20 degree angle and twist.

Quick snap is now locked firmly.

CAUTION: Trying to remove the canopy while it is locked into place may cause damage.




Use a flexible conduit only




MOUNTING INSTRUCTIONS (see FIG 3 to 7) The fixture is suitable for wall mounting, side mounting and ceiling mounting.

1. Open the front cover by flat head screwdriver (see Fig #3)
2. Knockout the appropriate mount screw hole and cable hole. Mount the back plate on the wall after feeding the AC cable into the back plate (see Fig #4)
3. For the ceiling and side mounting purpose, remove the mounting hole cover on the top or side of the unit. (See Fig #4, 5, 6) assemble the canopy on the unit (see Fig #2)
4. Attach the crossbar to the junction box, set the longer blade of the crossbar touching the J-box.
5. Route the proper wires through the mounting hole out of the housing.
6. Make the electrical connections inside the J-box as the wiring diagram states. (See Fig #1)
7. Push the excess wire into the J-box, use the screws to tighten the canopy to the crossbar so that the canopy is securely fastened and tight against the wall.
8. Attach the battery connector to the PC board, restore the front cover on the unit.
9. If the pictogram direction assembled is not suitable, you can change the direction of the pictogram or replace it into the diffuser easily (see Fig #7)


Open Front Cover Fig #3




Wall Mounting Fig #4




Side Mounting Fig #5



Ceiling Mounting Fig #6



Change direction of pictogram Fig #7



1. Revoir les diagrammes en détail.
2. Tous les branchements électriques doivent être conformes aux codes et règlements locaux et au code national de l'électricité.
3. Débrancher l'alimentation du fusible ou du disjoncteur avant de réparer ou installer.
4. Ne pas utiliser à l'extérieur.
5. Ne pas installer à des endroits dangereux ou près d'appareils de chauffage au gaz ou électrique.
6. Ne pas laisser les cordons d'alimentation en contact avec une surface chaude.
7. Le matériel doit être installé à un endroit et une hauteur où il ne pourra être trafiqué par des personnes non autorisées.
8. L'utilisation d'accessoires n'est pas recommandée par le fabricant et peut être dangereuse.
9. Ne pas utiliser pour un usage autre que celui prévu par le fabricant.
10. Tout le câblage doit être effectué par un électricien certifié.
11. La batterie doit être chargée pendant 24 h avant la première utilisation.

DIAGRAMME DE CÂBLAGE (see FR #1)

Câblage c.a.

Brancher le fil blanc au fil neutre. Si 120 V, brancher le fil noir au fil actif. Si 347 V, brancher le fil rouge au fil actif. Mettre un bouchon sur le fil inutilisé.

ASSMEBLAGE DU COUVERCLE (see FR #2)




Insérer le couvercle à un angle de 20 degrés et tourner.

Le raccord rapide est maintenant en place.

ATTENTION : Le retrait du couvercle en position barrée peut causer des dommages.

Câblage UDC


Entrée 6-24 V c. c., le fil jaune est positif (+), le fil violet est négatif (-).




INSTRUCTIONS DE MONTAGE (see FR #3 to #7) Le luminaire peut être monté sur un mur, latéralement ou au plafond.

1. Ouvrir le couvercle avant avec un tournevis à tête plate (voir la figure 3)
2. Percer les trous de vis et de câble appropriés. Monter la plaque arrière sur le mur après y avoir passé le câble c. a. (voir figure #4)
3. Pour le montage au plafond ou latéral, retirer le couvercle du trou de fixation sur le dessus ou le côté de l'unité. (voir les figures #4, #5 et #6) assemble la canopée sur l'unité (voir la figure # 2)
4. Attacher la barre transversale à la boîte de jonction. Fixer le côté le plus long de la barre pour qu'il touche la boîte.
5. Faire passer le câblage approprié par le trou de montage de la base.
6. Effectuer les raccords électriques dans la boîte de jonction tel qu'indiqué dans le diagramme de câblage. (voir la figure #1)
7. Pousser le surplus de fil dans la boîte, utiliser les vis pour fixer le couvercle à la barre transversale pour qu'il soit solide et bien appuyé contre le mur.
8. Attacher le raccord de la batterie à la carte de circuits imprimés puis remettre le couvercle en place.
9. Si l'icône est dans le mauvais sens, vous pouvez changer le sens ou le replacer facilement dans le diffuseur. (voir figure #7)


Ouvrez Front Cover FR #3




Support de plafond FR #6



Support de mur FR #4



Côté Mounting FR #5



Changez la direction du pictogramme FR #7

