

MaxLite® GuardMax Round Security Wall Pack



General Safety Information

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- For Residential installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.
- **DO NOT INSTALL DAMAGED PRODUCT!**
- This fixture is intended to be connected to a properly installed and grounded UL listed junction box.



Picture is for illustration purposes only.
Your model may vary.

SECR Series

Operating Temperature: -40°C to 40°C
Rated Voltage: 120-277 Vac 50/60Hz

WARNING:

RISK OF ELECTRICAL SHOCK

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- Make all electrical and grounded connections in accordance with the National Electrical Code and any applicable local code requirements.
- All wiring connections should be capped with UL approved wire connectors.
- Do not handle energized fixture when hands are wet, when standing on wet or damp surfaces, or in water.

CAUTION:

RISK OF INJURY

- Wear gloves and safety glasses at all times when removing luminaire from carton, installing, servicing or performing maintenance.
- Avoid direct eye exposure to the light source while it is on.
- Account for small parts and destroy packing material, as these may be hazardous to children.

CAUTION:

RISK OF FIRE


- Keep combustible and other materials that can burn away from luminaire and lamp/lens
- **MIN 90°C SUPPLY CONDUCTORS.**

MaxLite® GuardMax Round Security Wall Pack




Standard Wiring Diagram

CAUTION: Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.




EM Wiring Diagram




Emergency Battery Back-up Models

1. Make sure that the battery and battery back-up driver are connected.




2. Emergency test button switch is located at the bottom of the luminaire.



MaxLite® GuardMax Round Security Wall Pack

Color Temperature (CCT) Switch

1. Adjust the CCT switch inside the luminaire to the desired color temperature.



NOTE: Add a bead of exterior grade silicone sealant around the perimeter of the wall pack on the wall to inhibit any moisture from attachment bolts.

Direct J-Box/Wall Installation

NOTE: Disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.

1. Remove the two (2) rubber plugs and loosen the two (2) screws on the frontside of the luminaire. **(FIG. 1)**
2. Remove the ½ NPT KO plug from the back of the luminaire. **(FIG. 2)**
3. Peel off the yellow sticker from the back of the round foam gasket, included in the packaging. Apply the round gasket to the round area on the back of the luminaire. **(FIG. 3)**
4. Secure the back plate of the luminaire to the j-box or mounting surface. **(FIG. 4)**
5. Make the wiring connections with the supply conductors according to the wiring diagram above. **(FIG. 5)**
6. If you do not wish to use the photocell, unplug the connector located at the top of the luminaire housing (behind the clear KO plug). **(FIG. 6)**
7. Secure the front of the luminaire to the back plate by retightening the two (2) screws that were removed in step 1. Reinsert the two (2) rubber plugs to cover the screws. **(FIG. 6)**




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6







MaxLite® GuardMax Round Security Wall Pack



Surface Conduit Installation

NOTE: Disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.

1. Remove the two (2) rubber plugs and loosen the two (2) screws on the frontside of the luminaire. **(FIG. 7)**
2. Remove the ½ NPT KO plug from the top of the luminaire. **(FIG. 8)**
3. Peel off the yellow sticker from the back of the round foam gasket, included in the packaging. Apply the round gasket to the round area on the back of the luminaire. **(FIG. 9)**
4. Secure the back plate of the luminaire to the mounting surface. **(FIG. 10)**
5. Make the wiring connections with the supply conductors according to the wiring diagram above. **(FIG. 11)**
6. If you do not wish to use the photocell, unplug the connector located at the top of the luminaire housing (behind the clear KO plug).
7. Secure the front of the luminaire to the back plate by retightening the two (2) screws that were removed in step 1. Reinsert the two (2) rubber plugs to cover the screws. **(FIG. 12)**

**Fig. 7****Fig. 8****Fig. 9****Fig. 10****Fig. 11****Fig. 12**

MaxLite® GuardMax Round Security Wall Pack



Warranty Information

MaxLite Inc. warrants its products for a minimum period of **FIVE (5)** years from the date of original purchase from MaxLite or its authorized distributor/dealer (the “Warranty Period”), as follows: If a Product fails to operate during the Warranty Period as a result of defects in materials or workmanship, MaxLite will, at its option, repair it, replace it with the same or like Product.

Please refer to Maxlite’s website (at <http://maxlite.com/resources/warranties>) for the complete terms and conditions of our warranty.

Limitation of Liability

THE FOREGOING WARRANTY IS EXCLUSIVE, AND IS THE SOLE REMEDY FOR ANY AND ALL CLAIMS, WHETHER IN CONTRACT, IN TORT OR OTHERWISE ARISING FROM THE FAILURE OF PRODUCT AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH WARRANTIES ARE HEREBY EXPRESSLY DISCLAIMED TO THE EXTENT PERMITTED BY LAW AND, IN ANY EVENT, SHALL BE LIMITED TO THE WARRANTY PERIOD SPECIFIED ABOVE. THE LIABILITY OF MAXLITE SHALL BE LIMITED TO THE TERMS OF THE EXPRESS WARRANTY SET FORTH HEREIN. IN NO EVENT WILL MAXLITE BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING, WITHOUT LIMITATION, DAMAGES RESULTING FROM LOSS OF USE, PROFITS, BUSINESS OR GOODWILL, LABOR COSTS, REMOVAL OR INSTALLATION COSTS, DECREASE IN THE LIGHT OUTPUT OF THE LAMP, AND/OR DETERIORATION IN THE LAMP’S PERFORMANCE, WHETHER OR NOT MAXLITE HAS BEEN ADVISED OF THE POSSIBILITY THEREOF. UNDER NO CIRCUMSTANCES SHALL MAXLITE’S ENTIRE LIABILITY FOR A DEFECTIVE PRODUCT EXCEED THE PURCHASE PRICE OF THAT PRODUCT. WARRANTY SERVICES PROVIDED UNDER THESE TERMS AND CONDITIONS DO NOT ENSURE THE UNINTERRUPTED OPERATION OF PRODUCTS; MAXLITE SHALL NOT BE LIABLE FOR DAMAGES CAUSED BY ANY DELAYS INVOLVING WARRANTY SERVICE.

This Limited Warranty gives you specific legal rights and you may also have other rights that may vary from state to state. Because some states or jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, this limitation may not apply to you.